

# Technical APPLICATION Guide

## Double Unit Warblers SC628W, SC628JW, SC628FW, SC628FJW

The double unit warbler models require two audible alarm units to generate the alternating warble sound. The following combinations of models are possible:

### Medium Loud - Fast Warble:

Use SC628D with SC628W (alternating 1900 Hz & 2900 Hz)  
Use SC628H with SC628W (alternating 2900 Hz & 4500 Hz)

### Medium Loud - Slow Warble:

Use SC628D with SC628JW (alternating 1900 Hz & 2900 Hz)  
Use SC628H with SC628JW (alternating 2900 Hz & 4500 Hz)

### Soft - Fast Warble:

Use SC628E with SC628FW (alternating 1900 Hz & 2900 Hz)

### Soft – Slow Warble:

Use SC628E with SC628FJW (alternating 1900 Hz & 2900 Hz)

### Wiring Diagram:

