

Technical APPLICATION Guide

Double Unit Warblers SC628W, SC628JW, SC628FW, SC628FJW

The double unit warbler models require two audible alarm units to generate the alternating warble sound. The following combinations of models are possible:

Medium Loud - Fast Warble:

Use SC628D with SC628W (alternating 1900 Hz & 2900 Hz)
Use SC628H with SC628W (alternating 2900 Hz & 4500 Hz)

Medium Loud - Slow Warble:

Use SC628D with SC628JW (alternating 1900 Hz & 2900 Hz)
Use SC628H with SC628JW (alternating 2900 Hz & 4500 Hz)

Soft - Fast Warble:

Use SC628E with SC628FW (alternating 1900 Hz & 2900 Hz)

Soft – Slow Warble:

Use SC628E with SC628FJW (alternating 1900 Hz & 2900 Hz)

Wiring Diagram:

